15 RED LED TAIL LIGHT

ITEM # CTL5701LED

UPauto.com

Installation Tips For LED Lights:

Before installation check all lights to be sure the current lights are working properly. Remove existing 2 screws holding on the original lens. Remove lens and bulb. To remove bulb push in and turn and release. Look in the socket for the high and low indexing slots, and orient the plug of the LED to match when inserting. To help reach into the deeper sockets, insert a flat blade screwdriver in the slot on the plug of the LED light, then push and turn the plug and let the plug seat and return to the out position. For lights with limited space, carefully wrap the LED light wires in a circle to tuck all into the housing. Replace lens screws and you are ready to go. Test the lights to be sure all functions work.

Note:

Many times a LED optimized flasher is recommended when LED parking lights, side markers and tail lights are installed. Ask your United Pacific dealer for part number 90652 or 90649.